



NOTES

1. INSTALL ANODE A MINIMUM OF 2-FEET BELOW PIPE DEPTH IN NATIVE SOIL.
2. MAXIMUM HORIZONTAL DISTANCE FROM ANODE TO LEAK REPAIR CLAMP IS 5-FEET.

CITY OF NAPA

UTILITIES DEPARTMENT

TITLE
LEAK REPAIR CLAMP - ANODE INSTALLATION

DRAWN BY: DF
 APPROVAL DATE: 09/2021
 SCALE: NTS
 REVISED DATE: 09/2021

CHECKED BY: SL
 APPROVED BY: DD
 DRAWING NO. W-24D