



NOTES:

1. INSTALL ANODE A MINIMUM OF 2-FEET BELOW PIPE DEPTH IN NATIVE SOIL.
2. MAXIMUM HORIZONTAL DISTANCE FROM ANODE TO LEAK REPAIR CLAMP IS 5-FEET.

CITY OF NAPA

PUBLIC WORKS DEPARTMENT

TITLE

LEAK REPAIR CLAMP - ANODE INSTALLATION

DRAWN BY: DCF

DATE: 07/2017

SCALE: NTS

FIELD NOTES:

CHECKED BY: MJH

APPROVED BY: MJH

DRAWING NO.

W-24D