



PLAN VIEW

SECTION A-A

BIORETENTION DESIGN NOTES

1. FOR USE WITH STORMWATER FACILITIES WITH SLOPED SIDES OR FLAT BOTTOMS.
2. PROVIDE SPOT ELEVATIONS ON PLANS (FE, OE, GIE, IE). SEE CITY STD SWQ-100 AND SWQ-101.
3. DROP FROM INLET TO AGGREGATE PAD WILL BE GREATER FOR PLANTERS.
3. CURB AND WALL DETAILS MAY BE MODIFIED BY CIVIL AND GEOTECHNICAL ENGINEERS AND APPROVED BY PUBLIC WORKS DEPARTMENT.
4. WHERE INLET FLOW VELOCITY IS HIGH, EXTEND COBBLE INTO FACILITY, BUT AVOID EXCESSIVE USE.

CONSTRUCTION NOTES

1. AFTER CONSTRUCTION PLACE SAND BAGS AT GUTTER OPENINGS TO KEEP STORM FLOWS FROM ENTERING FACILITY UNTIL VEGETATION IS ESTABLISHED.

CITY OF NAPA

PUBLIC WORKS DEPARTMENT

CURB CUT INLET
(WITH GRAVEL ENERGY DISSIPATION)

DRAWN BY: LFM

CHECKED BY: TCW

DATE: 06/2018

APPROVED BY: JRL

SCALE: NONE

DRAWING NO.

FIELD NOTES:

SWQ-122