



BIORETENTION DESIGN NOTES

1. FOR USE WITH STORMWATER FACILITIES WITH SLOPED SIDES.
2. BEST SUITED FOR FACILITIES WITH $< \text{OF} \leq$ THAN 2% LONGITUDINAL SLOPE.
3. PROVIDE ELEVATIONS AND STATIONING AND/OR DIMENSIONING FOR CHECK DAMS.
4. SPACE CHECK DAMS TO MAXIMIZE PONDING ACROSS ENTIRE CELL.
5. ENSURE THAT CHECK DAM ELEVATIONS DO NOT CAUSE STORMWATER TO OVERFLOW TO SIDEWALK.

CONSTRUCTION NOTES

1. DO NOT WORK DURING RAIN OR UNDER WET CONDITIONS.
2. KEEP ALL HEAVY MACHINERY OUTSIDE BIORETENTION AREA LIMITS.

CITY OF NAPA

PUBLIC WORKS DEPARTMENT

GRAVEL CHECK DAM

DRAWN BY:	LFM
APPROVAL DATE:	06/2018
SCALE:	NONE
REVISED DATE:	

CHECKED BY:	TCW
APPROVED BY:	JBL
DRAWING NO.	SWQ-130